

Recommended Box Mounting Method



$\frac{1}{4}$ " x $2\frac{1}{2}$ " Carriage Bolt and Nut

1" EMT One-Hole Strap
1 #8 x $\frac{1}{2}$ " Screw

Mounting Pole
1" EMT Conduit
 $7\frac{1}{2}$ ' Long with the Bottom $1\frac{1}{2}$ ' Buried in the Ground